







03. GUARD RAIL SINGLE RAIL BARRIERS

GR 90

BARRIERA SINGOLA
SINGLE-RAIL BARRIER




GR 90

ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS






M16 GALVANISED STEEL

WITH EXPANSION SCREW



WARNING
The distance of installation depends
on speed and weight of vehicle









GR 90

ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS



M16 GALVANISED STEEL

WITH EXPANSION SCREW





GR 90





ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS



WITH RESIN



WARNING
The distance of installation depends on speed and weight of vehicle



GR 90

ISTRUZIONI DI INSTALLAZIONE
ASSEMBLY INSTRUCTIONS



WITH RESIN

